

# STILLA

## ASSEMBLY INSTRUCTIONS



### 'Sycamore' 12x6

S3097

Every part needed to construct your shed is included inside the pack; cedar panels, doors, windows, hardware kits & roof sheeting. Please ensure you fully unpack all the parts & check against the parts checklist before contacting customer service about anything you believe may be missing. Thank-you!

## Caution

Please be careful when handling all components, some parts have sharp metal edges. Always wear work gloves, eye protection and long sleeves when assembling or maintaining your shed.

## Tools required for assembly

- Level
- Drill (capable of driving 100mm Batten Screw)
- Hammer
- Ladder
- 10mm Drill bit
- 6mm Drill bit
- Tape measure
- Phillips head drive
- Hex Head Drive (5/16')
- Safety glasses
- Gloves
- Circular/power saw (if heavy duty floor was chosen)
- 4mm Alan key
- Batten screw drive

## Before assembly

- Before proceeding with installation, we recommend viewing the Cedar Studio video at [www.stilla.com.au/installation/](http://www.stilla.com.au/installation/) or search Stilla Cedar Studios on Youtube. This doesn't show the installation in detail however it could give you some handy tips. Please note we haven't videoed the assembly of each shed however the video online is the Pioneer 20x10 and will give you an overall idea on how the installation process is completed.
- Remove all parts from packages and place in a safe place close to assembly area.
- Review all instructions; continue to refer to instructions throughout assembly – step by step.

## Preparing your site

- If you are installing your shed on the Stilla heavy duty floor, this can be placed on unlevelled surfaces and levelled up by using the 100x100 stumps provided.



**SYCAMORE 12x6 PARTS CHECKLIST**

| Part Code   | Checked | Part Description  | Qty |
|-------------|---------|---|-----|
| P           |         | Cedar Clad Ply Panel 900x2020mm   | 8   |
| WP          |         | Cedar Clad Window Ply Panel 1080x2020mm   | 2   |
| SWA         |         | Cedar Studio Window Assembly (add per additional WP)                              | 2   |
| DCD         |         | Double Colonial Door 710x1885mm   | 2   |
| G           |         | 6ft Ply Gable   | 2   |
| FWP         |         | Cedar Clad Ply Fixed Window Panel 1200x2020mm (option)                            |     |
| CP          |         | Corner Post 2015x65x20mm  | 4   |
| CS          |         | Cover Strip 2015x40x7mm   | 7   |
| CS          |         | Fixed Cover Strip 2015x40x7mm (4x per added fixed window)                         |     |
| SF          |         | 6ft Studio Fascia Pack (4pcs) - 140x20mm  | 1   |
| R           |         | Roof Rafter 870x70x45mm   | 8   |
| CT          |         | Collar Tie  | 2   |
| DDH         |         | Studio Double Door Head 1440x123x45mm   | 1   |
| DDSS        |         | Double Door Surround Set – 2@ 1440mm, 2@ 1870mm (17x17)                           | 1   |
| DDS         |         | Double Door Vertical Seal – 1855x55x20mm  | 1   |
| SIWS        |         | Studio Internal Window Strip Set – 2@ 770mm, 2@ 1240mm<br>(add per additional WP) | 2   |
| E           |         | Roof End Piece 203x70x30mm  | 12  |
| RS          |         | 1120mm Roof Sheet   | 10  |
| RS          |         | 1120mm Roof Sheet Single Pan  | 2   |
| Sky         |         | 1450mm Skylight (option- swap with 1120 RS)                                       |     |
| RC          |         | 1520mm Ridge Cap  | 3   |
| C           |         | 1307mm Channel  | 6   |
| HK          |         | 12x6 Hardware Kit   | 1   |
| IM          |         | 12x6 Instruction Manual   | 1   |
| REP         |         | Roof End Plate 1754x70x45mm   | 8   |
| JP          |         | Joining Plate 1112x70x45mm  | 4   |
| RI (option) |         | Roof Insulation 3600x1300mm   | 2   |

**Floor Kit – Option**

Floor Frame – 140 x 35mm

| Part Code | Checked | Part Description    | Qty |
|-----------|---------|---------------------|-----|
| EP        |         | End Plate 1884mm    | 4   |
| DJ        |         | Double Joist 1730mm | 4   |
| SJ        |         | Single Joist 1730mm | 6   |
| L         |         | Logs 750mm          | 6   |
| FB        |         | 1798mm x 800mm      | 4   |
| FB        |         | 1798mm x 306mm      | 1   |



**Annex Kit – Option (add screws)**

3920mm x 1450mm

| <b>Part Code</b> | <b>Checked</b> | <b>Part Description</b>                | <b>Qty</b> |
|------------------|----------------|--|------------|
| VBJ              |                | Veranda Beam Joiner 700x70x45mm        | 1          |
| VOBJ             |                | Veranda Outer Beam Joiner 700x140x35mm | 1          |
| VB               |                | Veranda Beam 1960x70x45mm              | 2          |
| VOB              |                | Veranda Outer Beam 1960x140x35mm       | 2          |
| VR               |                | Veranda Rafter 1320x70x45mm            | 4          |
| VF               |                | Veranda fascia 1350x140x20 block cedar | 2          |
| VRS              |                | 1450mm Veranda Roof Sheet              | 6          |
| VP               |                | Veranda Posts 2400x90x90mm             | 2          |

**Annex Deck Kit – Option (add screws)**

3600mm x 1420mm

| <b>Part Code</b> | <b>Checked</b> | <b>Part Description</b>           | <b>Qty</b> |
|------------------|----------------|-----------------------------------|------------|
| VEP              |                | Veranda End Plate 3600x140x35mm   | 2          |
| VJ               |                | Veranda Joists 1350x140x35        | 9          |
| VFB              |                | Veranda Floorboards 3650x140x20mm | 11         |
| VL               |                | Veranda Logs 750x100x100mm        | 3          |



***If no floor option was purchased, go to step 2.0 (Wall Assembly)***

**SKIP TO BACK FOR IMAGES TO HELP WITH FLOOR INSTALL**

## STEP 1.0

### FLOOR KIT



#### 1.0 – FLOOR KIT (1 of 2 floor frames)

| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| EP        | 2   | End Plate 1884mm    |
| SJ        | 3   | Single Joist 1730mm |
| DJ        | 2   | Double Joist 1730mm |
| 100BS     | 24  | 100mm Batten Screw  |

#### 1.0 – FLOOR FRAME (1 of 2 floor frames)

Fasten floor frame together as indicated in diagram below, using lines and predrilled holes. Screw through EP into DJ using 3x 100BS. Screw through EP into SJ using 2 x 100BS per join. Ensure frame is square by measuring from corner to corner diagonally, frame will be square when both diagonal measurements equal the same.

**REPEAT THIS PROCESS FOR FASTENING 1 MORE FLOOR FRAME.**



**ENSURE 42x35 side of the DJ sits at top.**



## STEP 1.1

### FLOOR FRAME INSTALLATION

The 12x6 floor frame comes in two parts. Install first floor frame in desired position at desired height and fasten to logs once level and square, then join and fasten next frame and repeat.

#### 1.1 – FLOOR FRAME INSTALLATION

| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| L         | 6   | Logs 750x100x100mm  |
| 100BS     | 24  | 100mm batten screws |
| 65BS      | 8   | 65mm Batten Screws  |
| 200PB     | 6   | 200mm M12 Post Bolt |
| W         | 12  | M12 Washers         |

#### 1.1 – FLOOR FRAME INSTALLATION

Repeat the steps below for each floor frame, joining the floor frames together as you go in order displayed in diagram below.

1. Lay out frame in desired position and mark holes to dig, as indicated on diagram below (use shovel or marking paint).
2. Dig and place logs in holes (using concrete if you wish).
3. Fasten floor frame to logs at desired height, using 4x 100BS per log, ensuring frame is level\*.
4. Butt next floor frame into installed frame and join using 8x 65BS evenly spaced along the EP.
5. Repeat process until all frames are joined.

\* Fasten frame to logs when roughly level and then critique by hammering in or adding dirt (or concrete) to corners until perfectly level at every post.

Once all frames are joined, predrill holes (using a 13mm drill bit) and bolt each log to the floor frame in spots indicated with 200PB, using washers on both sides.





# STEP 1.2

## FLOOR INSTALLATION

| 1.2 – FLOORING INSTALLATION |     |                        |
|-----------------------------|-----|------------------------|
| PART CODE                   | QTY | DESCRIPTION            |
| FB                          | 4   | Floor Board 1798x800mm |
| FB                          | 1   | Floor Board 1798x306mm |
| 50PS                        | 75  | 50mm Philips Screw     |

**1.2– FLOORING INSTALLATION**  
 Fasten floor sheets to floor frame as shown in diagram below using 50PS.  
 Bring Floor sheets in **47mm** on two EP sides from the outside of the floor frame and **44mm** from the two DJ sides as seen below.  
**Note- The x marked on the floor sheets do not line up with our joists.**




## STEP 2.0

### DOUBLE DOOR WALL PANEL LAYOUT

The 12x6 Sycamore comes standard with a double door in the non-gable end of the shed with two window panels either side, as seen in the plan below. Follow the steps outlined in the following pages to assemble this plan in the correct order.

*Note: Any additional window panels purchased can be positioned and replace any of the 900 panels (9P) seen on this plan.*





# STEP 2.1

## WALL ASSEMBLY

### 2.1 - ASSEMBLY PARTS – WALL ASSEMBLY


| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| WP        | 1   | 1080mm Window Panel |
| P         | 1   | 900mm Panel         |
| 65HHS     | 3   | 65mm Hex head screw |

### 2.1 - ASSEMBLY – WALL ASSEMBLY


Screw through WP into P (top, centre & bottom) using 3 x 65HHS\*. Cedar strip on FWP or FP should be on the door side.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**



**IMPORTANT CORNER DETAIL:**  
Install frame flush on the outside of plywood bracing.



## STEP 2.2

### WALL ASSEMBLY

#### 2.2 - ASSEMBLY PARTS – WALL ASSEMBLY


| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| P         | 1   | 900mm Panel         |
| 65HHS     | 3   | 65mm Hex head screw |

#### 2.2 - ASSEMBLY – WALL ASSEMBLY

Screw through P into P (top, centre & bottom) using 3 x 65HHS\*.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**



## STEP 2.3

### WALL ASSEMBLY

#### 2.3 - ASSEMBLY PARTS – WALL ASSEMBLY


| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| P         | 1   | 900mm Panel         |
| 65HHS     | 3   | 65mm Hex head screw |

#### 2.3 - ASSEMBLY – WALL ASSEMBLY


Screw through P into P (top, centre & bottom) using 3 x 65HHS\*.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**



**IMPORTANT CORNER DETAIL:**  
Install frame flush on the outside of plywood bracing.



## STEP 2.4

### WALL ASSEMBLY

#### 2.4 - ASSEMBLY PARTS – WALL ASSEMBLY


| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| P         | 1   | 900mm Panel         |
| 65HHS     | 3   | 65mm Hex head screw |

#### 2.4 - ASSEMBLY – WALL ASSEMBLY

Screw through P into P (top, centre & bottom) using 3 x 65HHS\*.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**



## STEP 2.5

### WALL ASSEMBLY

#### 2.5 - ASSEMBLY PARTS – WALL ASSEMBLY

| PART CODE | QTY | DESCRIPTION |
|-----------|-----|-------------|
|-----------|-----|-------------|

|   |   |             |
|---|---|-------------|
| P | 1 | 900mm Panel |
|---|---|-------------|


|       |   |                     |
|-------|---|---------------------|
| 65HHS | 3 | 65mm Hex head screw |
|-------|---|---------------------|

#### 2.5 - ASSEMBLY – WALL ASSEMBLY

Screw through P into P (top, centre & bottom) using 3 x 65HHS\*.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**





## STEP 2.6

### WALL ASSEMBLY

#### 2.6 - ASSEMBLY PARTS – WALL ASSEMBLY

| PART CODE | QTY | DESCRIPTION |
|-----------|-----|-------------|
|-----------|-----|-------------|

|   |   |             |
|---|---|-------------|
| P | 1 | 900mm Panel |
|---|---|-------------|


|       |   |                     |
|-------|---|---------------------|
| 65HHS | 3 | 65mm Hex head screw |
|-------|---|---------------------|

#### 2.6 - ASSEMBLY – WALL ASSEMBLY

Screw through P into P (top, centre & bottom) using 3 x 65HHS\*.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**



# STEP 2.7

## WALL ASSEMBLY

### 2.7 - ASSEMBLY PARTS – WALL ASSEMBLY


| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| P         | 1   | 900mm Panel         |
| 65HHS     | 3   | 65mm Hex head screw |

### 2.7 - ASSEMBLY – WALL ASSEMBLY


Screw through P into P (top, centre & bottom) using 3 x 65HHS\*.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**



**IMPORTANT CORNER DETAIL:**  
Install frame flush on the outside of plywood bracing.



## STEP 2.8

### WALL ASSEMBLY

#### 2.8 - ASSEMBLY PARTS – WALL ASSEMBLY

| PART CODE | QTY | DESCRIPTION |
|-----------|-----|-------------|
|-----------|-----|-------------|

|   |   |             |
|---|---|-------------|
| P | 1 | 900mm Panel |
|---|---|-------------|


|       |   |                     |
|-------|---|---------------------|
| 65HHS | 3 | 65mm Hex head screw |
|-------|---|---------------------|

#### 2.8 - ASSEMBLY – WALL ASSEMBLY

Screw through P into P (top, centre & bottom) using 3 x 65HHS\*.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**





# STEP 2.9

## WALL ASSEMBLY

### 2.9 - ASSEMBLY PARTS – WALL ASSEMBLY


| PART CODE | QTY | DESCRIPTION               |
|-----------|-----|---------------------------|
| WP        | 1   | 1080mm Front Window Panel |
| 65HHS     | 3   | 65mm Hex head screw       |

### 2.9 - ASSEMBLY – WALL ASSEMBLY


Screw through WP into P (top, centre & bottom) using 3 x 65HHS\*. Cedar strip on FWP or FP should be on the door side.

*\* It helps to have one person adjusting from the outside and one person screwing on the inside.*

**Note: Ensure tongue on cedar cladding is at top.**



**IMPORTANT CORNER DETAIL:**  
Install frame flush on the outside of plywood bracing.





# STEP 3.0

## DOOR HEAD INSTALL

| 3.0 - ASSEMBLY PARTS – DOOR HEAD INSTALL |     |                                |
|--|-----|--------------------------------|
| PART CODE                                | QTY | DESCRIPTION                    |
| DDH                                      | 1   | 1440x123x45mm Double Door Head |
| MP                                       | 2   | Mending Plate                  |
| 32PS                                     | 8   | 32mm Phillips Screw            |

- 3.0 - ASSEMBLY – DOOR HEAD INSTALL**
1. Mark 75mm either side on top of door head (tongue is on top).
  2. Screw Mending Plate to top of either side of Door Head using 2x 32PS.
  3. Place Door Head in position. Ensure back of Door Head sits flush with back frame of front panel.
  4. Fasten Door Head by screwing 2x 32PS through mending plate into front panel. **Ensure Door Head sits hard against side of front panel.**



Ensure Door Head sits hard against side of front panel and flush with back frame.



# STEP 3.1

## DOOR HEAD INSTALL

| 3.1 - ASSEMBLY PARTS – DOOR HEAD INSTALL |     |                    |
|--|-----|--------------------|
| PART CODE                                | QTY | DESCRIPTION        |
| 100BS                                    | 2   | 100mm Batten Screw |

**3.1 - ASSEMBLY – DOOR HEAD INSTALL**  
 Secure Door Head by screwing 1x 65HHS through front panel into bottom of Door Head, as seen below.  
*\* Predrill 4mm hole before screwing.*



## STEP 3.2

### DOOR SURROUND INSTALL

#### 3.2 - ASSEMBLY PARTS – DOOR SURROUND INSTALL

| PART CODE | QTY | DESCRIPTION   |
|-----------|-----|---|
| DDSS      | 1   | Double Door Surround Set – 2@ 1440mm, 2@ 1870mm (DD option) |
| 40N       | 20  | 40mm Nail   |

#### 3.2 - ASSEMBLY – DOOR SURROUND INSTALL

1. Nail top 1440mm Door Surround to bottom of door head (flush with back) using 4x 40N.  
 2. Nail bottom 1440mm door surround to floor frame (hard against flooring) using 4x 40N\*.  
 Ensure wall panels are tight against surround (there should be a 1440mm gap).

3. Measure and cut side 1870mm Door Surrounds to fit between top and bottom.

4. Nail side Door Surrounds, flush with back of wall panels, using 6x 40N per side.

*\* If floor frame was not purchased, secure bottom piece using silicone and concrete nails (not supplied).*

Nail surround flush  
with back of frame  
using 40N.





## STEP 3.3

### GABLE INSTALL

#### 3.3 - ASSEMBLY PARTS –GABLE INSTALL (1 of 2 Gables)

| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| G         | 1   | 6ft Gable           |
| 65HHS     | 4   | 65mm Hex head screw |


#### 3.3 - ASSEMBLY –GABLE INSTALL (1 of 2 Gables)

Carefully place gable on back wall, ensuring groove on gable slots into the tongue on the wall, as seen below. Ensure end of gable sits flush with side of back wall panel and fasten by screwing 4x 65HHS through panels into gable- 2 screws either side of join.


**REPEAT THIS PROCESS FOR INSTALLING OTHER SIDE GABLE.**



Ensure groove slots into tongue



Screw upwards through wall panel into gable




# STEP 4.0


## ROOF FRAME ASSEMBLY

| 4.0 - ASSEMBLY PARTS – ROOF ASSEMBLY (REPEAT TWICE) |     |                             |
|---|-----|-----------------------------|
| PART CODE   | QTY | DESCRIPTION                 |
| REP   | 4   | Roof End Plate 1754x70x45mm |
| R   | 4   | Roof Rafter 870x70x45mm     |
| JP  | 2   | Joining Plate 1112x70x45mm  |
| 75BS  | 40  | 75mm Batten Screw           |

**4.0 - ASSEMBLY – ROOF ASSEMBLY (1 of 2 frames)**  
 It helps to find a flat, level surface to complete this process on.



1. Position JP up to the 556mm line on REPs, hold flush and use predrilled holes to screw two Roof End Plates (REP) together with Joining Plate (JP) using 75BS (as pictured).  
**Repeat this twice.**



2. Place 4x Roof Rafters (R) in between joined REPs as seen in diagram above and screw 75BS into predrilled holes to finish assembling one roof frame.

**REPEAT THIS ASSEMBLY PROCESS TWICE TO COMPLETE BOTH ROOF FRAMES - ENSURE FRAMES ARE SQUARED BEFORE MOVING ON**



## STEP 4.1

### ROOF INSULATION INSTALL

*If you did not purchase this option please skip this step*

#### 4.1 - ASSEMBLY PARTS – ROOF INSULATION INSTALL (REPEAT TWICE)


| PART CODE   | QTY | DESCRIPTION                 |
|-------------|-----|-----------------------------|
| RI (option) | 1   | Roof Insulation 3600x1300mm |
| 40N         | 40  | 40mm Nail                   |

#### 4.1 - ASSEMBLY – ROOF INSULATION INSTALL (REPEAT WITH SECOND FRAME)

**It helps to find a flat, level surface to complete this process on.**

Once roof frame is assembled, fix Roof Insulation to top of frame before screwing roof sheets over top.

Fix Roof Insulation to top of frame using bent 40N (or staples- not supplied).



## STEP 4.2

### ROOF ASSEMBLY

| 4.2 - ASSEMBLY PARTS – ROOF ASSEMBLY (ROOF SHEETS) |     |                   |
|--|-----|-------------------|
| PART CODE  | QTY | DESCRIPTION       |
| RS   | 2   | 1120mm roof sheet |
| 40RS   | 2   | 40mm Roof screw   |
| 25RS   | 2   | 25mm Roof screw   |

**4.2 - ASSEMBLY – ROOF ASSEMBLY (ROOF SHEETS)**

**It helps to find a flat, level surface to complete this process on.**

Position roof sheets (RS) at either end of roof frame and fasten in place as indicated in diagrams. Lay roof sheet (bent edge) flush with top of roof frame while hanging side of roof sheet **203mm\*** over end of roof frame. Once in position, screw 25RS through pan at top\*\* FIRST and then (checking bottom is still overhanging 203mm from side) screw a 40RS through rib at the bottom\*\* to fasten roof sheet in place.

*\* Use 203mm “E” or tape measure when placing overhanging side of roof sheet (ENSURE ROOF SHEET RUNS PARRELEL TO ROOF FRAME END).*

*\*\* Only screw 25RS in pan at the top and 40RS in the bottom of roof sheet.*

**Hang side of roof sheet, 203MM over end of roof frame** (TOP)

**Bent up edge at top**

**(SIDE VIEW)**

**(END VIEW)**

**REPEAT THIS STEP FOR SECOND ROOF FRAME**






# STEP 4.3

## ROOF ASSEMBLY

| 4.3 - ASSEMBLY PARTS – ROOF ASSEMBLY (ROOF SHEETS) |     |                              |
|--|-----|------------------------------|
| PART CODE  | QTY | DESCRIPTION                  |
| RS   | 3   | 1120mm roof sheet            |
| RS   | 1   | 1120mm single pan roof sheet |
| 40RS   | 5   | 40mm Roof screw              |
| 25RS   | 10  | 25mm Roof screw              |

**4.3 - ASSEMBLY – ROOF ASSEMBLY (ROOF SHEETS)**  
 Complete laying roof sheeting out on frame. Fasten roof sheets to battens in sequence shown. 1 x 25RS either side of join at top and 1 x 40RS through rib join at bottom.  
*Note: Use straight edge to keep all screws in line and centre of batten.*



## STEP 4.4

### ROOF ASSEMBLY


#### 4.4 - ASSEMBLY PARTS – ROOF ASSEMBLY

| PART CODE | QTY | DESCRIPTION     |
|-----------|-----|-----------------|
| 40RS      | 18  | 40mm Roof screw |
| 25RS      | 16  | 25mm Roof screw |

#### 4.4 - ASSEMBLY – ROOF ASSEMBLY

Complete screwing roof off at top. 1 x 25RS in pan beside every rib. Once top is complete screw bottom off using 1 x 40RS through every rib.

*Note: Use straight edge to keep all screws in line and centre of batten.*



**REPEAT THIS STEP FOR SECOND ROOF FRAME**



## STEP 4.5

### CHANNEL ASSEMBLY


*If you purchased the Annex, leave the channel off the side you will be installing your Annex*

| 4.5 - ASSEMBLY PARTS – CHANNEL ASSEMBLY |     |                         |
|---|-----|-------------------------|
| PART CODE                               | QTY | DESCRIPTION             |
| ST                                      | 9   | 12mm self-tapping screw |
| C                                       | 3   | Roof Channel            |

**4.5 - ASSEMBLY – CHANNEL ASSEMBLY**


Slide Roof channel onto end of roof sheeting overhang. Fasten in place using ST.

(TOP)



|         |       |     |
|---------|-------|-----|
| 1120 RS |       |     |
| REP     | 870 R | REP |

**REPEAT TASKS 4.0 – 4.5 TO COMPLETE THE OTHER ROOF PANEL.**





## STEP 4.6

### ROOF END PIECE

#### 4.6 - ASSEMBLY PARTS – RIDGE BEAM BRACKET

| PART CODE | QTY | DESCRIPTION                |
|-----------|-----|----------------------------|
| E         | 12  | Roof End Piece 203x70x30mm |
| 65BS      | 12  | 65 Batten Screws           |

#### 4.6 - ASSEMBLY – ROOF END PIECES TO GABLES

Standing inside shed on ladder, screw roof end pieces to top of gable in required positions using 1x 65BS per piece. See positions in photo below. Lay 70mm side flat on top of gable with 70x30mm face flush with inside of gable frame and screw in place (6 pieces per gable).

**Note: It is advised to predrill through the E first with a 4mm drill bit, before securing to gable.**

**Repeat this step on both gables.**



## STEP 4.7

### ROOF INSTALLATION


#### 4.7 - ASSEMBLY PARTS – ROOF INSTALLATION

| PART CODE | QTY | DESCRIPTION           |
|-----------|-----|-----------------------|
|           | 2   | Completed roof panels |
| 75BS      | 20  | 75mm Batten Screw     |
| 125BS     | 4   | 125mm Batten Screw    |

#### 4.7 - ASSEMBLY – ROOF INSTALLATION

Slide roof frame into position. Ensure point of roof frame is flush with middle of gable as seen below. Fasten to ends using 3x 75BS, screw through roof frame into gable frame. Fasten to sides using 4x 75BS evenly spaced, screw through roof frame into side wall top plates, use 2x 125BS for middle of side, through JP. Meet second roof frame up with the first and repeat steps for fastening.

***This task will require 2 or more persons to complete.***



## STEP 4.8

### ROOF INSTALATION

#### 4.8 - ASSEMBLY – ROOF INSTALLATION

| PART CODE | QTY | DESCRIPTION      |
|-----------|-----|------------------|
| 40RS      | 8   | 40mm Roof Screws |
| 25RS      | 8   | 25mm Roof Screws |

#### 4.8 – ASSEMBLY – ROOF INSTALLATION

Fully fasten down the roof sheeting onto the Roof End Pieces (E) as seen below. Use 2x 25RS to screw into the top E of each side and 2x 40RS to screw into the bottom E of each side.

*Note: there is four sides.*





## STEP 4.9

### COLLAR TIE INSTALLATION

#### 4.9 – ASSEMBLY PARTS – COLLAR TIE INSTALLATION

| PART CODE | QTY | DESCRIPTION        |
|-----------|-----|--------------------|
| CT        | 2   | Collar tie         |
| 40RS      | 12  | 40mm Roof Screw    |
| 125BS     | 12  | 125mm Batten Screw |

#### 4.9 - ASSEMBLY – COLLAR TIE INSTALLATION

Holding Collar tie tight and level in position screw through CT into Roof Rafters in predrilled holes, using 6x 40RS per collar tie.

Fasten roof frames together by screwing 125BS evenly space along the top of the roof frames.



# STEP 5.0

## DOUBLE DOOR HINGE ASSEMBLY

### 5.0 - ASSEMBLY PARTS – DOUBLE DOOR HINGE ASSEMBLY

| PART CODE | QTY | DESCRIPTION          |
|-----------|-----|----------------------|
| BH        | 6   | Butt Hinge           |
| HS        | 24  | Hinge Screw          |
| DCD       | 2   | Double Colonial Door |

### 5.0 - ASSEMBLY – DOUBLE DOOR HINGE ASSEMBLY

1. Place door on side and measure out hinge positions as seen below.
2. **Ensure hinge join sits on outside of door/studio and the edge sits flush with edge of door as seen below.**
3. Place hinges in required positions and screw to side using 4x HS\*.

\* 3mm Predrill is recommended before fastening hinges to door.

#### **Repeat step with second door.**

Place hinges 100mm from top and bottom and centre of door (893mm mark), as seen below.



Ensure Butt sits on exterior side of door.

Screw hinge once edge is flush with interior of door





# STEP 5.1

## DOUBLE DOOR INSTALLATION

### 5.1 - ASSEMBLY PARTS – DOUBLE DOOR INSTALLATION

| PART CODE | QTY | DESCRIPTION           |
|-----------|-----|-----------------------|
| DCD       | 2   | Double Colonial Doors |
| HS        | 24  | Hinge screw           |

### 5.1 - ASSEMBLY – DOUBLE DOOR INSTALLATION

Mark top door hinge placement on side panel, 105mm from bottom of door head. (so door sits 5mm down from top).

Holding the door in position, parallel to shed\*, attach door by screwing 6x HS per hinge into side panel frame\*\*. ***This is easier with two people, one to hold the door in place and another to attach the door.***

\* Front of door should be facing shed panels.

\*\* It is recommended to only screw one HS in the top and bottom hinge and check the door is in the right position before screwing all (door should sit 5mm down from top).



## STEP 5.2

### DOUBLE DOOR SEAL INSTALLATION

#### 5.2 - ASSEMBLY PARTS – DOUBLE DOOR SEAL INSTALLATION

| PART CODE | QTY | DESCRIPTION                              |
|-----------|-----|--|
| DDS       | 1   | Double Door Vertical Seal – 1855x55x20mm |
| 40N       | 8   | 40mm Nail                                |

#### 5.2 - ASSEMBLY – DOUBLE DOOR SEAL INSTALLATION

Choose fixed door (generally left hand door). Position flat side of DDS 15mm down from top of door and 40mm in from side and nail to back of fixed door using 8x 40N (as seen below).



Mark 15mm down from top of door.

Mark 40mm in from side of door.

Nail DDS to door using 8x 40N evenly spaced along DDS.



## STEP 5.3

### BARREL BOLT INSTALL

#### 5.3 – ASSEMBLY PARTS – BARREL BOLT INSTALL

| PART CODE | QTY | DESCRIPTION       |
|-----------|-----|-------------------|
| BB        | 2   | Barrel Bolt       |
| BBS       | 8   | Barrel Bolt Screw |

#### 5.3 - ASSEMBLY – BARREL BOLT INSTALL

Hold Barrel Bolt in position, hard against Door Seal, and fasten to door using 4x BBS per Barrel Bolt (as seen below). Hold door in closed position, mark centre of bolt and drill 9mm hole. Repeat for bottom barrel bolt.

*Note- T-Handle must be installed on the opposite door to the fixed door (door with barrel bolts).*

Fasten Barrel Bolt to door.



Mark centre of bolt.



Drill 9mm hole.





# STEP 5.4

## DOOR HANDLE ASSEMBLY

### 5.4 - ASSEMBLY PARTS – DOOR HANDLE ASSEMBLY

| PART CODE | QTY | DESCRIPTION |
|-----------|-----|-------------|
| TH        | 1   | T Handle    |

### 5.4 - ASSEMBLY – DOOR HANDLE ASSEMBLY

1. Find suitable height for T Handle (generally 1050mm up door).
2. Mark and drill 12mm centre hole in position, 40mm in from door edge.
3. Insert T handle in position and mark two outside holes.
4. Remove T handle and drill 2 x 6mm holes.
5. Insert T handle back in with bolts and fasten nuts on back of door.



Drill 6mm holes and fasten t-handle to door with bolts, nuts, and washers.



## STEP 5.5

### DOOR HANDLE ASSEMBLY

#### 5.5 - ASSEMBLY PARTS – DOOR HANDLE ASSEMBLY

| PART CODE | QTY | DESCRIPTION     |
|-----------|-----|-----------------|
| DL        | 1   | D-Handle Leaver |

#### 5.5 - ASSEMBLY – DOOR HANDLE ASSEMBLY

Holding door in closed position, flush with other door - slide leaver onto T Handle and tighten using a 4mm allen key once hitting Seal on fixed door.





## STEP 5.6

### WINDOW ASSEMBLY INSTALLATION

#### 5.6 - ASSEMBLY PARTS – WINDOW ASSEMBLY INSTALLATION

| PART CODE | QTY | DESCRIPTION            |
|-----------|-----|------------------------|
| SWA       | 2   | Studio Window Assembly |
| 32PS      | 40  | 32mm Phillips screw    |

#### 5.6 - ASSEMBLY – WINDOW ASSEMBLY INSTALLATION

Fit Window Assembly into hole in Window Panel\*. Ensuring the window frame is square, fasten to Window Panel by screwing through perimeter of Window Panel hole into SWA\*\*. Use 4x 32PS in top and bottom of SWA and 6x 32PS for sides.

\* Ensure window opens the side that suits you, flip Window Assembly to change.

\*\* It is advised to predrill using a 3mm drill bit before screwing.

Repeat process for second window and any additional windows.



# STEP 5.7

## INTERNAL WINDOW STRIP ASSEMBLY

| 5.7 - ASSEMBLY PARTS – INTERNAL WINDOW STRIP ASSEMBLY |     |   |
|---|-----|---|
| PART CODE   | QTY | DESCRIPTION   |
| SIWS  | 2   | Studio Internal Window Strip Set- 2@ 770mm, 2@ 1240mm |
| 40N   | 40  | 40mm Nail   |


- 5.7 - ASSEMBLY – INTERNAL WINDOW STRIP ASSEMBLY**
1. Measure 25mm around perimeter of Window Panel hole.
  2. Position and nail top 770mm strip using 4x 40N.
  3. Position and Nail left side 1240mm strip using 6x 40N.
  4. Position and Nail right side 1240mm strip and bottom 770mm strip together using 6x 40N for side and 4x 40N for bottom (adjust to line up).

**Repeat process for second window and any additional windows.**



**1. Measure 25mm around outside.**

**2. Nail top 770mm strip**



**3. Nail left 1240mm strip**

**Nail 1x 40N in bottom & right strip and then align bottom right corner.**

**4. Align bottom right corner and then finish nailing bottom & right strips.**





# STEP 6.0

## CORNER POST ASSEMBLY

| 6.0 - ASSEMBLY PARTS – CORNER POST ASSEMBLY |     |                    |
|---|-----|--------------------|
| PART CODE                                   | QTY | DESCRIPTION        |
| CP  | 4   | 2015mm Corner Post |
| 40N   | 24  | 40mm Nail          |

**6.0 - ASSEMBLY – CORNER POST ASSEMBLY**

Hold corner post (CP) in position, nail through CP into wall stud using 6x 40N evenly spaced along CP. Repeat for all four corners.

*Note: Before nailing CPs, we recommend running a bead of silicone down the lines seen below.*

**Recommended: Run a bead of silicone down these two lines before nailing CPs**





# STEP 6.1

## COVER STRIP ASSEMBLY

### 6.1 - ASSEMBLY PARTS – COVER STRIP ASSEMBLY

| PART CODE | QTY | DESCRIPTION        |
|-----------|-----|--------------------|
| CP        | 7   | 2015mm Cover Strip |
| 40N       | 42  | 40mm Nail          |


### 6.1 - ASSEMBLY – COVER STRIP ASSEMBLY

Hold cover strips (CS) over joints in walls and beside door/s, nail through CS into wall panel using 6x 40N evenly spaced per CS.

**Note:** Before nailing CS, we recommend running a bead of silicone down the joints in the wall, as seen below.



**Recommended: Run a bead of silicone down joints before nailing CS**



**Nail 6x 40N evenly spaced along CS**



## STEP 6.2


### FASCIA ASSEMBLY

#### 6.2 - ASSEMBLY PARTS – FASCIA ASSEMBLY

| PART CODE | QTY | DESCRIPTION |
|-----------|-----|-------------|
| F         | 4   | Fascia      |
| 40N       | 24  | 40mm Nail   |

#### 6.2 - ASSEMBLY – FASCIA ASSEMBLY

Hold fascias in position, parallel with Ends and join evenly at top. Nail 2x 40N through fascia into End pieces to fasten.



## STEP 6.3

### RIDGE CAP INSTALLATION

#### 6.3 - ASSEMBLY PARTS – RIDGE CAP INSTALLATION

| PART CODE | QTY | DESCRIPTION      |
|-----------|-----|------------------|
| RC        | 3   | Ridge Cap 1520mm |
| 40RS      | 12  | 40mm Roof screw  |

#### 6.3 - ASSEMBLY – RIDGE CAP INSTALLATION

Slide ridge cap into position. Make sure peak of ridge cap is in line with peak of fascias. Screw through ridge cap into 2<sup>nd</sup> rib in from end and through into roof batten. Slide second and third ridge caps into position and fasten at opposite end. Ensure ridge cap is straight, fasten through the centre overlaps, both sides.





## STEP 6.4

### EXTERNAL FIXED WINDOW STRIP ASSEMBLY

*If you did not purchase a fixed window panel, please skip this step.*


#### 6.4 - ASSEMBLY PARTS – COVER STRIP ASSEMBLY

| PART CODE | QTY | DESCRIPTION                           |
|-----------|-----|---------------------------------------|
| CS        | 4   | 2015mm Cover Strip (per fixed window) |
| 40N       | 20  | 40mm Nail (per fixed window)          |

#### 6.4 - ASSEMBLY – COVER STRIP ASSEMBLY

Mark 3mm around perimeter of window. Mark and cut side strips to size. Nail Side strips using 6x 40N per side. Mark and cut top and bottom strips to size. Nail top and bottom strips using 4x 40N per.

**Note: Before nailing CS, we recommend running a bead of silicone down the joins in the wall, as seen below.**



Mark 3mm around window

Measure, mark and cut side strips to size

Nail Side strips using 6x 40N

Measure, mark and cut top & bottom strips. Nail using 4x 40N




## STEP 6.5

### 6.5 - ASSEMBLY PARTS – FIXING TO BASE

| PART CODE | QTY | DESCRIPTION         |
|-----------|-----|---------------------|
| 65HHS     | 11  | 65mm Hex Head Screw |

### 6.5 - ASSEMBLY – FIXING TO BASE

Once shed is in desired position and doors are sitting evenly you can now fix your shed to the base. Fix either side of Double Doors, at each corner and at each join of panel. It is recommended that fixings are every 900mm. Screws/Dyna bolts are to be fastened through the bottom plate. If your shed is going on a concrete slab – fasteners are not supplied.



## STEP 7.0

### ANNEX FRAME ASSEMBLY


*If you did not purchase this option please skip this step*

| 7.0 - ASSEMBLY PARTS – ANNEX FRAME |     |  |
|------------------------------------|-----|--|
| PART CODE                          | QTY | DESCRIPTION                            |
| VB                                 | 2   | Veranda Beam 1960x70x45mm              |
| VBJ                                | 1   | Veranda Beam Joiner 700x70x45mm        |
| VOB                                | 2   | Veranda Outer Beam 1960x140x35mm       |
| VOBJ                               | 1   | Veranda Outer Beam Joiner 700x140x35mm |
| VR                                 | 4   | Veranda Rafter 1320x140x45mm           |
| 65BS                               | 14  | 65mm Batten Screw                      |
| 100BS                              | 8   | 100mm Batten Screw                     |


### 7.0 - ASSEMBLY – ANNEX FRAME

**It helps to find a flat, level surface to complete this process on.**


1. Join Veranda Beams (VB) together using Veranda Beam Joiner (VBJ). Mark 350mm (middle) on VBJ and Butt Veranda Beams into each other, hold flush and fasten together using 3x 65BS each through VBJ into VB, as seen below.




2. Join Veranda Outer Beams (VOB) together using Veranda Outer Beam Joiner (VOBJ). Mark 350mm (middle) on VOBJ and Butt Veranda Outer Beams into each other, hold flush and fasten together using 4x 65BS each through VOBJ into VOB, as seen below.



3. Assemble veranda frame. Place 4x Veranda Rafters (VR) in between joined VB and VOB, as seen below. Hold VR 70mm side flush with top and screw through beams, using 1x 100BS per join. **It is advised to predrill through beams before screwing rafters.**







# STEP 7.1

## ANNEX ROOF

| 7.1 - ASSEMBLY PARTS – ANNEX ROOF |     |                           |
|-----------------------------------|-----|---------------------------|
| PART CODE                         | QTY | DESCRIPTION               |
| VRS                               | 2   | 1450mm Veranda Roof Sheet |
| 40RS                              | 2   | 40mm roof screw           |
| 25RS                              | 2   | 25mm roof screw           |

**7.1 - ASSEMBLY – ANNEX ROOF**

**It helps to find a flat, level surface to complete this process on.**

Position veranda roof sheets (VRS) at either end of roof frame and fasten in place as indicated in diagrams. Lay roof sheet (bent edge) flush with top of veranda frame with side of roof sheet sitting **flush** with end of veranda frame. Once in position, screw 25RS through pan at top\* **FIRST** and then screw a 40RS through rib at the bottom\* to fasten roof sheet in place.

*\*Only screw 25RS in pan at the top and 40RS in the bottom of roof sheet.*



## STEP 7.2

### ANNEX ROOF


#### 7.2 - ASSEMBLY PARTS – ANNEX ROOF

| PART CODE | QTY | DESCRIPTION               |
|-----------|-----|---------------------------|
| VRS       | 4   | 1450mm veranda roof sheet |
| 40RS      | 5   | 40mm Roof screw           |
| 25RS      | 10  | 25mm Roof screw           |

#### 7.2 - ASSEMBLY – ANNEX ROOF

Complete laying roof sheeting out on frame. Fasten roof sheets to beams in sequence shown. 1 x 25RS either side of join at top and 1 x 40RS through rib join at bottom.

*Note: Use straight edge to keep all screws in line and centre of beam.*



## STEP 7.3

### ANNEX ROOF


#### 7.3 - ASSEMBLY PARTS – ANNEX ROOF

| PART CODE | QTY | DESCRIPTION     |
|-----------|-----|-----------------|
| 40RS      | 20  | 40mm Roof screw |
| 25RS      | 20  | 25mm Roof screw |

#### 7.3 - ASSEMBLY – ANNEX ROOF

Complete screwing roof off at **top**. 1 x 25RS in pan **beside every rib**. Once top is complete screw **bottom** off using 1 x 40RS **through every rib**.

*Note: Use straight edge to keep all screws in line and centre of batten.*




## STEP 7.4

### ANNEX ROOF CHANNEL

TURN BACK TO PAGE 26, **STEP 4.4**, TO FASTEN CHANNEL TO ANNEX ROOF





## STEP 7.5

### ANNEX ROOF INSTALATION

#### 7.5 - ASSEMBLY PARTS – ANNEX ROOF INSTALLATION

| PART CODE | QTY | DESCRIPTION                |
|-----------|-----|----------------------------|
| VP        | 2   | Veranda Posts 2400x90x90mm |
| 100BS     | 6   | 100mm batten screw         |
| 200PB     | 4   | 200mm M12 Post Bolt        |
| W         | 8   | M12 Washer                 |

#### 7.5 - ASSEMBLY – ANNEX ROOF INSTALLATION

- Using at least 3 people, butt the veranda roof hard up under shed roof as seen below. Support front of veranda roof while fastening through frame into shed wall studs, using 4x 100BS.
- If installing on dirt\*- dig holes and place posts in ground as seen in diagram on previous page (using concrete if you wish).
- Once veranda frame is at desired height, screw through front beam into posts using 1x 100BS to hold posts in desired position\*\* (**ENSURE THERE IS 30mm FALL DOWN FROM SHED TO FRONT OF VERANDA ROOF**).
- Once posts are level in the desired position and veranda frame has **30mm of fall**, predrill holes (using a 13mm drill bit) and secure posts to VOB with 2x 200PB and 4x W.

\* If installing on concrete pad, use brackets and dyno bolt into place (fasteners not supplied).

\*\* Fasten frame to posts once roughly the right height and then critique by hammering in or adding dirt (or concrete) till there is precisely **30mm fall from shed**.





## STEP 7.6

### ANNEX FASCIA

#### 7.6 - ASSEMBLY PARTS – ANNEX FASCIA

| PART CODE | QTY | DESCRIPTION                            |
|-----------|-----|--|
| VF        | 2   | Veranda fascia 1350x140x20 block cedar |
| 40N       | 8   | 40mm nail                              |

#### 7.6 - ASSEMBLY – ANNEX FASCIA

Once fascia's are on shed, trim annex fascia to butt in and finish correctly. Nail through fascia using 4 x 40N per fascia.





IMAGES TO HELP WITH INSTALLATION


FLOOR























## TO REGISTER YOUR WARRANTY

Thank-you for purchasing a STILLA product. To register your 10 year product warranty, please go to [www.stilla.com.au/warranty](http://www.stilla.com.au/warranty) and complete the online form. We recommend that you complete this step once you have finished installing your product.

**PLEASE NOTE THAT IF YOU DO NOT COMPLETE THIS WARRANTY REGISTRATION FORM – YOUR PRODUCT IS NOT COVERED BY WARRANTY.**

## PRODUCT MAINTENANCE

We highly recommend you coat the external of your product with Intergrain UltraDeck Timber Stain – in the Colour Light Oak. This product is available from Dulux paint stores or Bunnings stores that have a paint section. The product is re tinted from a Cedar Cypress base to achieve the light oak colour – Intergrain is a Cabot's product (Having issues – Bring up Cabot's page on the paint desk computer and type Light Oak – this should bring up the formula)





24/10/2023

## SHOW US YOUR SHED

We would love to see a photo of your STILLA product installed in your backyard. Please upload this image when completing the warranty registration. Alternatively, you can send the photos by email to [sales@stilla.com.au](mailto:sales@stilla.com.au).

If you require any assistance, please feel free to call or email.

Kind regards,

**STILLA** Customer Support

1800 784 552 | [sales@stilla.com.au](mailto:sales@stilla.com.au)

